

Aqua Stopper Pipeline Closure Plugs 4 pipes

Technical Data

Nylon Edition				
				
Sealing range		Article No.	Max. water pressure* in bar	Thread size (Inch)
Min. pipe ID in mm	Max. pipe ID in mm			
48.5	62	13920	1	1/2
74	86	13921	1	1/2
95.5	105	13922	0.3	1/2

Aluminium Edition				
				
Sealing range		Article No.	Max. water pressure* in bar	Thread size (Inch)
Min. pipe ID in mm	Max. pipe ID in mm			
38	50	13930	1.5	1/2
49	62	13931	1.5	1/2
62	77	13932	1.5	1/2
73	89	13933	1	1/2
84	103	13934	1	1/2
94	110	13935	0.5	1/2
112	130	13936	0.5	1/2
125	142	13937	0.5	1/2
146	168	13938	0.5	1/2
175	200	13939	0.5	1
193	220	13940	0.5	1
220	240	13941	0.5	1
245	270	13942	0.5	1
277	328	13943	0.5	1
295	325	13944	0.5	1
325	360	13945	0.3	1
350	385	13946	0.3	1
370	410	13947	0.3	1
390	435	13948	0.3	1
445	495	13949	0.3	2
495	550	13950	0.2	2
595	650	13951	0.2	2

*with additional holding fixture

Application

For a perfect function of the Aqua Stopper please consider the following points:

1. The pipeline inner diameter must fit to the sealing range of the chosen model.
2. Clean the stopper before and after application.
3. The Aqua Stopper should be positioned at a right angle to the pipe, close to the pipe end.
4. Close wingnut.
5. For a pressure test we strongly recommend a separate holding fixture for sealing and safety reasons.

The 4 pipes warranty only applies to faulty material. Checking the suitability of the product for the individual application is solely the responsibility of the user.